



- 1.-FOR LEGEND SEE DWG. AND LIGHTING FIXTURE
- 2.-FOR TYPICAL SUBSTATION
- 3.-REMOVE RECEPTACLE AND ABANDON CONDUIT IN FLOOR AND PLUG CONDUIT.
- 4.-SUPPORT EXISTING EQUIPMENT
- 5.-REMOVE ABANDONED FIRE ALARM
- 6.-REMOVE AND INSTALL NEW ON PLAN AND DESCRIBE: A.-CUT EXISTING CONDUIT 2'-0\"/>
- 7.-INTERCEPT AND REROUTE PROVIDE JUNCTION BOX CONDUIT SECTION AS SHOWN

